






## Repair Code Description

1	Replace 240v 13A plug – plastic
2	Replace 240v 13A plug – rubber
3	Change plug fuse 3A
4	Change plug fuse 5A
5	Change plug fuse 10A
6	Change plug fuse 13A
7	Replace 240v trailing socket
8	Replace 240v 16A plug
9	Replace 240v 16A connector
10	Replace 110v 16A plug
11	Replace 110v 16A connector
12	Replace 110v 16A panel mount socket
13	Trim, refit cable to appliance
14	Trim, refit cable to plug, or socket
15	Trim, refit cable to 240/110v 16A plug/connector/socket
16	Trim refit cable to 3-phase plug/connector/socket
17	Replace 15A/5A/2A plug
18	Trim, refit cable to fuse connection unit
19	Fit 10A flexible lead connector
20	Replace 1.5 Arctic Yellow/Blue cable 0-2m
21	Replace 1.5 Arctic Yellow/Blue cable 3-5m
22	Replace 1.5 Arctic Yellow/Blue cable 6-10m
23	Replace 1.5 Arctic Yellow/Blue cable 11 -1 5m
24	Replace 2.5 Arctic Yellow cable 0-2m
25	Replace 2.5 Arctic Yellow cable 3-5m
26	Replace 2.5 Arctic Yellow cable 6-10m
27	Replace 2.5 Arctic Yellow cable 11-15m
28	Replace 1.5 3 Core cable 0-2m
29	Replace 1.5 3 Core cable 3-5m
30	Replace 1.5 3 Core cable 6-10m
31	Replace 1.5 3 Core cable 11-15m
32	Replace 1.0 3 Core cable 0-2m
33	Replace 1.0 3 Core cable 3-5m
34	Replace 1.0 3 Core cable 6-10m
35	Replace 1.0 3 Core cable 11-15m
36	Replace 0.75 2 Core cable 0-2m
37	Replace 0.75 2 Core cable 3-5m
38	Replace 0.75 2 Core cable 6-10m
39	Replace 0.75 2 Core cable 11-15m
40	Supply 4 way extension lead complete
41	Supply and fit 4 way trailing socket
42	Supply and fit 2 way trailing socket
43	Supply kettle lead/complete with plug
44	Replace IEC plug/socket
45	Replace IEC computer lead
46	Replace cotton covered flex 2-3m
47	Fit 13A flex connector
48	Supply class 2 reversible mains lead
49	Fit 16/20/25mm cord grip bush
50	Fit strain relief bush